

# App Inventor + IoT: Flying bees with Micro:bit Magnetometer sensor



(with Basic Connection  
tutorial completed)

## Level: advanced


This tutorial will help you get started with App Inventor + IoT and the magnetometer sensor on a [BBC micro:bit](#) controller.

## Hardware

You only need one [BBC micro:bit](#) to get started with this project.

## Pairing with Micro:bit

First, you will need to pair your phone or tablet to the micro:bit controller, using these [directions](#). Your device must be paired with the micro:bit in order for the app to work.



## App Inventor

This app can let you control a small Bee icon in the app to move around according the magnetic field around micro:bit. Now log into [MIT App Inventor site](#) and create a new project.


You should complete the [App Inventor + IoT Basic Connection tutorial](#) to make a basic connection to the micro:bit device. If you prefer, you can download the completed .aia file [here](#).

- [App Inventor's micro:bit magnetometer component's document](#)

The remaining steps all build off of [the starter app for Basic Connection tutorial and .aia](#).

First, we need to add the necessary extension.


- In the Palette window, click on Extension at the bottom and then on "Import extension" and click on "URL".
  - Paste in this URL:  
`http://iot.appinventor.mit.edu/assets/com.bbc.micro:bit.profile.aia`
- Add a **Microbit\_Magnetometer** extension to your app by dragging it onto the Viewer, set its **BluetoothDevice** to "BluetoothLE1"(Don't forget!).



Let's add more components to our app to read the magnetometer status.

- From the Drawing and animation drawer in the Palette, drag in a **Canvas** and an **ImageSprite**. Set Canvas's height to 320 pixels, width to fill parent (or any size you like).
  - Set **ImageSprite**'s Picture to some cute image (no bigger than the canvas).
- Add four Label to show Magnetometer's X, Y, Z axis and bearing value.

Your designer page should look like this:




## Now switch to the Blocks Editor view

We would like to control ImageSprite's heading by the Z-axis movement of magnetometer on micro:bit controller. Let's begin:

### STEP 1: Request updates when connected


In the **BluetoothLE1.Connected** event, we show messages and tell the micro:bit to update the magnetometer's state.

And in the **Microbit\_Magnetometer1.WroteMagnetometerPeriod** event, we show the related message and the period value just set.



### STEP2: Show bearing value

Whenever the Micro:bit's bearing value is changed(**Microbit\_Magnetometer1.MagnetoBearingReceived** event), we show the bearing value on the label.





### STEP3: Show XYZ data and control ImageSprite

Same idea, whenever the magnetic situation around Micro:bit is changed (**Microbit\_Magnetometer1.MagnetoDataReceived** event),

we do things below:

- Set **ImageSprite**'s heading to **Magnetometer\_Z** value.
- Show X, Y and Z axis value on corresponding label, check image below for micro:bit's axis.



(From <https://makecode.microbit.org> )

## Tips

Your app should now be working! Make sure you have paired the Bluetooth on your Android device to your micro:bit. Then test it out by connecting your micro:bit device using the MIT AI2 Companion (if you haven't already) or installing it by .apk. Try to shake or flip around your micro:bit or have a small magnet (not too strong or it may influence your device!) point toward it, you should see the App Inventor logo turning and turning!

## Brainstorming

1. Try to add more cute movement into your app, for example, you can use X and Y axis values to make ImageSprite move left and right and show something when it bumps the edge of the Canvas. (Refer to our [Micro:bit button tutorial](#)).
2. Add some sound effects when the magnetosensor value have exceeded certain level.